


# DecoFlex WireFree™ RTS Table Top Control Accessory

## ASSEMBLY INSTRUCTIONS


Part #1810972Silver(Silver Top)

Part #1811051Lounge(Black Top)

The DecoFlex WireFree™ RTS Table Top Control Accessory extends the benefits and versatility of the standard DecoFlex WireFree™ RTS wall switch. This unique accessory enhances the style of the decor and is ergonomically designed for comfortable hand-held use and ideal for placement on coffee tables, kitchen islands/counters, bedroom night stands or anywhere that permits easy access for controlling RTS motorized window coverings.



1. Position DecoFlex switch assembly into table top accessory base.
2. Align table top accessory cover with DecoFlex switch assembly.
3. Secure table top accessory base to cover using screws provided.



## FCC INFORMATION

This device complies with Part 15 of the FCC Results. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including that which may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for CLASS B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna
2. Increase the separation between the equipment and receiver
3. Connect the equipment into an outlet on a circuit different from that to which receiver is connected
4. Consult the dealer or experienced radio/TV technician for help.

**WARNING: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.**

**SOMFY SYSTEMS, INC.**  
**North America Headquarters**  
121 Herrod Boulevard  
Dayton, NJ 08810  
Phone: US: 1-800-22-SOMFY  
NJ: (609) 395-1300  
Fax: General (609) 495-8117

**FLORIDA**  
6100 Broken Sound Pkwy. N.W.,  
Suite 14  
Boca Raton, FL 33487  
Phone: (877) 227-6639  
Fax: (561) 995-7502

**CALIFORNIA**  
15291 Barranca Parkway  
Irvine, CA 92618-2201  
Phone: (877) 727-6639  
Fax: (949) 727-3775

**SOMFY ULC**  
**SOMFY Canada Division**  
6315 Shawson Drive, Unit #1  
Mississauga, Ontario L5T1J2  
Phone: CN: 1-800-66-SOMFY  
CN: (905) 564-6446  
Fax: (905) 564-6448

SOMFY SYSTEMS, INC. reserves the right to change, update or improve this document without prior notice.