



HomeSeer Motion Sensor HS-MS100+ Manual

[Home](#) » [HomeSeer](#) » HomeSeer Motion Sensor HS-MS100+ Manual 



Contents

1 HomeSeer

2 Motion Sensor

2.1 SKU: HS-MS100+

2.2 Quickstart

2.3 Important safety information

2.4 What is Z-Wave?

2.5 Product Description

2.6 Prepare for Installation / Reset

2.6.1 Reset to factory default

2.7 Inclusion/Exclusion

2.7.1 Inclusion

2.7.2 Exclusion

2.8 Communication to a Sleeping device (Wakeup)

2.9 Quick trouble shooting

2.10 Association – one device controls an other device

2.10.1 Association Groups:

2.11 Configuration Parameters

2.11.1 Parameter 12: MOTION SENSORS SENSITIVITY

2.11.2 Parameter 14: ENABLE/DISABLE BASIC SET COMMAND

2.11.3 Parameter 15: VALUE OF THE BASIC SET

2.11.4 Parameter 17: ENABLE/DISABLE SHOCK ALARM

2.11.5 Parameter 18: MOTION ALARM CANCELLATION DELAY

2.11.6 Parameter 32: LEVEL OF LOW BATTERY

2.12 Technical Data

2.13 Supported Command Classes

2.14 Controlled Command Classes

2.15 Explanation of Z-Wave specific terms

2.16 Related Posts

HomeSeer

Motion Sensor

SKU: HS-MS100+





Quickstart

This is a
secure
Alarm Sensor
for
U.S. / Canada / Mexico.

Please make sure the internal battery is fully charged.

To add this device to your network execute the following action:

- 1) Open the cover.
- 2) Place the device within the direct range of your Z-Wave controller.
- 3) Set the main controller in add mode (see the controllers manual).
- 4) Click the Z-button once or triple click the Z-button quickly, the LED indicator should blink fast.
- 5) Wait for the adding process to end.
- 6) Successful adding will be confirmed by the Z-Wave controllers message.

Please refer to the [Manufacturers Manual](#) for more information.

Important safety information

Please read this manual carefully. Failure to follow the recommendations in this manual may be dangerous or may violate the law.

The manufacturer, importer, distributor and seller shall not be liable for any loss or damage resulting from failure to comply with the instructions in this manual or any other material.

Use this equipment only for its intended purpose. Follow the disposal instructions.

Do not dispose of electronic equipment or batteries in a fire or near open heat sources.

What is Z-Wave?

Z-Wave is the international wireless protocol for communication in the Smart Home. This device is suited for use in the region mentioned in the Quickstart section.

Z-Wave ensures a reliable communication by reconfirming every message (**two-way communication**) and every mains powered node can act as a repeater for other nodes (**meshed network**) in case the receiver is not in direct wireless range of the transmitter.



This device and every other certified Z-Wave device can be **used together with any other certified Z-Wave device regardless of brand and origin** as long as both are suited for the same frequency range.

If a device supports **secure communication** it will communicate with other devices secure as long as this device provides the same or a higher level of security. Otherwise it will automatically turn into a lower level of security to maintain backward compatibility.

For more information about Z-Wave technology, devices, white papers etc. please refer to www.z-wave.info.

Product Description

Motion sensor can be included and operated in any Z-Wave network with other Z-Wave certified devices. The features list: 1) Z-Wave Plus certified for wide compatibility (500 series product). 2) Supports security 0 and security 2 protected mode with AES-128 encryption. 3) Motion sensor. 4) Tamper alarm by shock sensor. 5) The battery life is up to 1 year. 6) Low battery alarm. 7) Support firmware OTA.

Prepare for Installation / Reset

Please read the user manual before installing the product.

In order to include (add) a Z-Wave device to a network it **must be in factory default state**. Please make sure to reset the device into factory default. You can do this by performing an Exclusion operation as described below in the manual. Every Z-Wave controller is able to perform this operation however it is recommended to use the primary controller of the previous network to make sure the very device is excluded properly from this network.

Reset to factory default

This device also allows to be reset without any involvement of a Z-Wave controller. This procedure should only be used when the primary controller is inoperable.

1) Power on the device, 2) Press and hold the Z button for more than 20 seconds, 3) If holding time more than 20 seconds, the LED indicator will keep on for 2 seconds, which means resetting is complete. 4) The reset feature works only when the device has been included into a Z-Wave network. Use this procedure only in the event that the network primary controller is missing or otherwise inoperable.

Inclusion/Exclusion

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

Inclusion

1) Open the cover. 2) Place the device within the direct range of your Z-Wave controller. 3) Set the main controller in add mode (see the controllers manual). 4) Click the Z-button once or triple click the Z-button quickly, the LED indicator should blink fast. 5) Wait for the adding process to end. 6) Successful adding will be confirmed by the Z-Wave controllers message.

Exclusion

1) Open the cover. 2) Place the device within the direct range of your Z-Wave controller. 3) Set the main controller remove mode (see the controllers manual). 4) Triple click the Z-button quickly, the LED indicator should blink fast. 5) Wait for the removing process to end. 6) Successful adding will be confirmed by the Z-Wave controllers message.

Communication to a Sleeping device (Wakeup)

This device is battery operated and turned into deep sleep state most of the time to save battery life time. Communication with the device is limited. In order to communicate with the device, a static controller **C** is needed in the network. This controller will maintain a mailbox for the battery operated devices and store commands that can not be received during deep sleep state. Without such a controller, communication may become impossible and/or the battery life time is significantly decreased.

This device will wakeup regularly and announce the wakeup state by sending out a so called Wakeup Notification. The controller can then empty the mailbox. Therefore, the device needs to be configured with the desired wakeup interval and the node ID of the controller. If the device was included by a static controller this controller will usually perform all necessary configurations. The wakeup interval is a tradeoff between maximal battery life time and the desired responses of the device. To wakeup the device please perform the following action:

Press and hold the Z button for more than 5 seconds and release.

Quick trouble shooting

Here are a few hints for network installation if things dont work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.
4. Never use sleeping battery devices without a central controller.
5. Dont poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

Association – one device controls an other device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command wireless command, typically a 'Basic Set' Command.

Association Groups:

Group Number Maximum Nodes Description

1	5	Z-Wave Plus Lifeline:1. Notification Report.Sensor will send Notification Report to the associated nodes when Motion Sensor is removed or/and PIR is triggered.2. Battery Report.Motion Sensor will send Battery Report when the battery level is low and the battery reports value is 0xFF.3. Device Reset Locally Notification.
2	5	1. Basic Set.Motion Sensor will send Basic Set to associated nodes when the PIR is triggered.

Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration can adapt the function better to user needs or unlock further enhanced features.

IMPORTANT: Controllers may only allow configuring signed values. In order to set values in the range 128 ... 255 the value sent in the application shall be the desired value minus 256. For example: To set a parameter to 200 it may be needed to set a value of 200 minus 256 = minus 56. In case of a two byte value the same logic applies: Values greater than 32768 may needed to be given as negative values too.

Parameter 12: MOTION SENSORS SENSITIVITY

The higher the value, the more sensitive the PIR sensor.

Size: 1 Byte, Default Value: 8

Setting Description

1 – 8	The higher the value, the more sensitive the PIR sensor.
-------	--

Parameter 14: ENABLE/DISABLE BASIC SET COMMAND

Motion sensor can send BASIC SET command to nodes associated with group 2 when motion is triggered.

Size: 1 Byte, Default Value: 0

SettingDescription

0	Disable
1	Enable

Parameter 15: VALUE OF THE BASIC SET

Motion Sensor can reverse its value of BASIC SET when motion is triggered.

Size: 1 Byte, Default Value: 0

SettingDescription

0	Send BASIC SET VALUE = 255 to nodes associated with group 2 when motion alarm is triggered. Send BASIC SET VALUE = 0 to nodes associated with group 2 when motion alarm is canceled.
1	Send BASIC SET VALUE = 0 to nodes associated with group 2 when motion alarm is triggered. Send BASIC SET VALUE = 255 to nodes associated with group 2 when motion alarm is canceled.

Parameter 17: ENABLE/DISABLE SHOCK ALARM

Size: 1 Byte, Default Value: 0

SettingDescription

0	when the value is 0, the product will not send a vibration alarm after moving or shaking; when the value is 1, the product will send a vibration alarm after moving or shaking
1	

Parameter 18: MOTION ALARM CANCELLATION DELAY

Motion alarm will be cancelled in the main controller after 3 seconds, the alarm cancellation can be delayed by this parameter. Any motion detected during the cancellation delay time countdown will result in the countdown being restarted.

Size: 2 Byte, Default Value: 0

SettingDescription

0	Reports are not sent
1 – 65535	the change in luminance level resulting in luminance report being sent to the main controller.

Parameter 32: LEVEL OF LOW BATTERY

Define a battery level as the low battery.

Size: 1 Byte, Default Value: 20

SettingDescription

10 – 50	The low level from 10% to 50%
---------	-------------------------------

Technical Data

Hardware Platform	ZM5101
Device Type	Notification Sensor
Network Operation	Reporting Sleeping Slave
Firmware Version	HW: 1 FW: 1.00
Z-Wave Version	6.71.01
Certification ID	ZC10-17125907
Z-Wave Product Id	0x000C.0x0201.0x0009
Firmware Updatable	Updatable by Consumer by RF
Sensors	Air Temperature
Supported Notification Types	Home Security
Color	White
Security V2	S2_UNAUTHENTICATED
Frequency	XXfrequency
Maximum transmission power	XXantenna

Supported Command Classes

- Association Grp Info
- Association V2
- Battery
- Configuration
- Device Reset Locally
- Firmware Update Md V3
- Manufacturer Specific V2
- Notification V5
- Powerlevel
- Security
- Security 2
- Supervision
- Transport Service V2
- Version V2
- Wake Up V2
- Zwaveplus Info V2

Controlled Command Classes

- Basic

Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network.

Controllers are typically Gateways, Remote Controls or battery operated wall controllers.

- **Slave** — is a Z-Wave device without capabilities to manage the network.
Slaves can be sensors, actuators and even remote controls.
- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and a controlled device.
- **Wakeup Notification** — is a special wireless message issued by a Z-Wave device to announce that it is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.