


The user manual fits for Smart Door Sensor as
bellows:

Smart door sensor:

E1D-G73



Features

- Door opened or door closed status are reported to Sengled home app, and home hub display, as well as web portal
- Report the current battery remaining capacity.
- Zigbee Alliance certified.

Package Includes

- Two E1D-G73 smart door sensors
- User manual and user guide

Product Specifications

- Power: Battery Li+ CR1632
- Input: 3V dc, Li+
- Installation method: paste on the door or window surface close to opening or closing edge
- Size: 21mm (10mm)* 49mm* 12mm / 0.83(0.39) in* 1.93in * 0.47in
- Operating Temperature: 5°C ~ +40°C / 41°F ~ 104 °F
- Operating Humidity: 0 RH 95%, non-condensing
- Wireless zigbee 3.0, 2.4GHz (2402~2482MHz,802.11b/g/n).

Installation Instructions

Adding the sengled door sensor to any smart home hub involves the following steps:


Step 1: Download the Sengled Home App.



Step 2: Register and sign-in to your Sengled account in the app.

Step 3: Open the Sengled Home App, go to Devices and use "+" choose icon "A. Element Door Sensor" then scan QR code to add sensors, or choose icon "B. scan QR code " to add your Door Sensors directly.

If you don't have a hub in your account, you should add a hub firstly. If you have other brand hub, you can refer to the item "Installation Instructions Using a Third-party hub".



Step 4: Remove to the power isolation tab found in the door sensor, the red LED indicator in the door sensor will flash twice to indicator to be in pairing mode.

Note: There will be only 1min in pairing mode after removing the power isolation tab.

Step 5: Follow in-app instructions to finish installation. The red LED indicator in the door sensor will flash 3 times after adding to hub successfully.

Congratulations on successfully installing your smart bulbs.

Troubleshoot the device

1) If the smart door sensor could not connect the Sengled hub:
Press and hold on the button with a needle with package for 4-8 seconds, then release it, the door sensor will be reset to factory mode and waiting for joining a hub.

Note: There will be only 1 min in pairing mode. If the door sensor could not pair in this 1 min, it will be in sleepy mode.

2) If the battery remain capacity is limited, replacing the battery:
Open the main part of Sengled door sensor manual, replace the same size CR1632 Li+ battery. **Pay attention to the battery polarity. Please DO NOT use a tweezers or a conductive object to clip the battery.**

Operations of the bulb

• Rejoin wireless network from the door sensor

Press and hold on the button with a needle within 1 second, the red LED indicator in the door sensor will flash once, the door sensor will be in rejoin mode, it can rejoin that original hub once.

• Factory default reset

Press and hold on the button with a needle with package for 4-8 seconds, then release it, the door sensor will be reset to factory mode and waiting for joining a hub.

CAUTION

- **INDOOR USE ONLY**
- **DO NOT USE WEHRE DIRECTLY EXPOSED TO WATER**



FCC ID: 2AGN8- E1DG73
IC: 20888- E1DG73

Federal Communications Commission (FCC) Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF exposure warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.

IC Radiation Exposure Statement for Canada

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation

est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit

accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut

fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

User manuals for transmitters equipped with detachable antennas shall also contain the following notice in a conspicuous location:

This radio transmitter (identify the device by certification number, or model number if

Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio (identifier le dispositif par son numéro de certification ou son numéro de modèle s'il fait partie du matériel de catégorie I) a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette

liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

IMPORTANT NOTE:

Radiation Exposure Statement:

This equipment complies with "Industry Canada RSS-102 for radiation exposure limits set forth for an uncontrolled environment". This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Hereby, Sengled Co., Ltd. declares that this device E1D-G73 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.sengled.com

sengled
www.sengled.com

© 2019 Sengled, Incorporated. All rights reserved. Sengled is a trademark of Sengled, Incorporated, registered in the United States and other countries. Specifications are subject to change without notice. Other trademarks and trade names are the property of their respective owners.